

Kramer Electronics, Ltd.



USER MANUAL

Model:

VP-8x8

8x8 VGA / UXGA Matrix Switcher

Contents

1	Introduction	1
2	Getting Started	1
3	Overview	2
3.1	Terminology Used in this User Manual	3
4	Your VP-8x8 8x8 VGA / UXGA Matrix Switcher	3
5	Connecting the VP-8x8	6
5.1	Connecting the VP-8x8 Rear Panel	6
5.2	Controlling via RS-232 (for example, using a PC)	8
5.3	Controlling via RS-485	9
5.4	Control Configuration via the Ethernet Port	10
5.4.1	Connecting the ETHERNET Port directly to a PC (Crossover Cable)	10
5.4.2	Connecting the ETHERNET Port via a Network Hub (Straight-Through Cable)	12
5.4.3	Control Configuration via the Ethernet Port	12
5.5	Setting the Dipswitches	13
5.5.1	Setting the Delay	13
5.5.2	Setting the Machine # Dipswitches	14
5.6	Cascading Machines	14
6	Operating the VP-8x8	15
6.1	Displaying Unit Characteristics	16
6.2	Confirming Settings	16
6.2.1	Toggling between the At Once and Confirm Modes	17
6.2.2	Confirming a Switching Action	17
6.3	Storing/Recalling Input/Output Configurations	17
6.3.1	Storing an Input/Output Configuration	18
6.3.2	Recalling an Input/Output Configuration	18
6.3.3	Deleting an Input/Output Configuration	18
6.4	Locking the Front Panel	19
7	Flash Memory Upgrade	20
7.1	Downloading from the Internet	20
7.2	Connecting the PC to the RS-232 Port	20
7.3	Upgrading Firmware	20
8	Technical Specifications	26
9	Table of Hex Codes for Serial Communication	27
10	Kramer Protocol 2000	28

Figures

Figure 1: VP-8x8 8x8 VGA / UXGA Matrix Switcher – Front and Rear View	4
Figure 2: VP-8x8 8x8 VGA / UXGA Matrix Switcher – Underside View	4
Figure 3: Connecting the VP-8x8 8x8 VGA / UXGA Matrix Switcher	7
Figure 4: Connecting a PC without using a Null-modem Adapter	8
Figure 5: Controlling via RS-485 (for example, using an RC-3000)	9
Figure 6: RJ-45 PINOUT	10
Figure 7: Local Area Connection Properties Window	11
Figure 8: Internet Protocol (TCP/IP) Properties Window	11
Figure 9: VP-8x8 Dipswitches	13
Figure 10: Control Configuration via RS-232 and RS-485	15
Figure 11: Storing and Recalling using the Input/Output Buttons	17
Figure 12: Splash Screen	21
Figure 13: Atmel – Flip Window	21
Figure 14: Device Selection Window	22
Figure 15: Selecting the Device from the Selection Window	22
Figure 16: Loading the Hex	23
Figure 17: RS-232 Window	23
Figure 18: Atmel – Flip Window (Connected)	24
Figure 19: Atmel – Flip Window (Operation Completed)	25

Tables

Table 1: Terminology Used in this User Manual	3
Table 2: Front Panel VP-8x8 8x8 VGA / UXGA Matrix Switcher Features	5
Table 3: Rear Panel VP-8x8 8x8 VGA / UXGA Matrix Switcher Features	5
Table 4: VP-8x8 Underside Panel Features	5
Table 5: Crossover Cable RJ-45 PINOUT	10
Table 6: Straight-through Cable RJ-45 PINOUT	12
Table 7: Dipswitch Settings	13
Table 8: DELAY Dipswitch Settings	13
Table 9: Machine # Dipswitch Settings	14
Table 10: STATUS 7-segment Display	16
Table 11: Technical Specifications of the VP-8x8 8x8 Video Matrix Switcher	26
Table 12: VP-8x8 Hex Codes for Switching via RS-232/RS-485	27
Table 13: Protocol Definitions	28
Table 14: Instruction Codes for Protocol 2000	29

ADDENDUM: Ethernet Cross Cable Wiring Connection

This addendum describes the correct wiring for crossover cable connections and replaces the opening paragraph in the "Connecting the ETHERNET Port directly to a PC (Crossover Cable)" section in the User Manual as follows:

Connecting the ETHERNET Port directly to a PC (Crossover Cable)

You can connect the Ethernet port of the machine to the Ethernet port on your PC, via a crossover cable with RJ-45 connectors.

Table 1 and Figure 1 define the color codes for the two existing standard types of cross cables used in the industry. Table 2 defines how to connect the wires to the connectors on both ends of the cable.

When manually connecting the ends of a cable, both connectors must follow the same standard (either EIA /TIA 568A or EIA /TIA 568B).

Table 1: Crossover Cable RJ-45 Types

EIA /TIA 568B		EIA /TIA 568A	
PIN	Wire Color	PIN	Wire Color
1	White-orange	1	White-green
2	Orange	2	Green
3	White-green	3	White-orange
4	Blue	4	Blue
5	White-blue	5	White-blue
6	Green	6	Orange
7	White-brown	7	White-brown
8	Brown	8	Brown




Figure 1: RJ-45 PINOUT

Table 2: Wiring between Connector One and Two of the Cable

Signal Pairs	PINs on Connector One	PINs on Connector Two	Signal Pairs
TX_D1+	1	3	RX_D2+
TX_D1-	2	6	RX_D2-
RX_D2+	3	1	TX_D1+
RX_D2-	6	2	TX_D1-
BI_D3+	4	7	BI_D4+
BI_D3-	5	8	BI_D4-
BI_D4+	7	4	BI_D3+
BI_D4-	8	5	BI_D3-

1 Introduction

Welcome to Kramer Electronics (since 1981): a world of unique, creative and affordable solutions to the infinite range of problems that confront the video, audio and presentation professional on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better! Our 500-plus different models now appear in 8 Groups¹, which are clearly defined by function.

Congratulations on purchasing your **VP-8x8** 8x8 *VGA / UXGA Matrix Switcher*, which is ideal for the following typical applications:

- Any professional display system requiring a true 8x8 computer graphics matrix operation
- Multimedia and presentation source, and acceptor selection

The package includes the following items:

- **VP-8x8** 8x8 *VGA / UXGA Matrix Switcher*
- Power cord and Null-modem adapter
- Windows®-based Kramer control software²
- Windows®-based Configuration Manager XPort software and Com Port Redirector
- Kramer **RC-IR1** Infra-Red Remote Control Transmitter³ (including the required battery and a separate user manual⁴)
- This user manual⁴

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
- Review the contents of this user manual
- Use Kramer high performance high resolution cables⁵

1 GROUP 1: Distribution Amplifiers; GROUP 2: Video and Audio Switchers, Matrix Switchers and Controllers; GROUP 3: Video, Audio, VGA/XGA Processors; GROUP 4: Interfaces and Sync Processors; GROUP 5: Twisted Pair Interfaces; GROUP 6: Accessories and Rack Adapters; GROUP 7: Scan Converters and Scalers; and GROUP 8: Cables and Connectors

2 Downloadable from our Web site at <http://www.kramerelectronics.com>

3 Previously known as the IR-1 / IR-1-01

4 Download up-to-date Kramer user manuals from our Web site at <http://www.kramerelectronics.com>

5 The complete list of Kramer cables is on our Web site at <http://www.kramerelectronics.com>

3 Overview

The **VP-8x8** is a high performance 8x8 RGBHV Matrix Switcher for high resolution video. The **VP-8x8** lets you simultaneously route any or all of the 8 inputs to any or all of the 8 outputs.

The **VP-8x8** 8x8 *VGA / UXGA Matrix Switcher*:

- Has a video bandwidth of 400MHz that ensures transparent performance even in the most critical applications
- Has 16 preset memory locations for quick access to common configurations
- Has a delayed switching mode (ranging from 0 to 3.5sec¹) for clean transitions (seamless switching) when switching between non-genlocked sources
- Has DC coupled inputs and outputs
- Includes a TAKE button, which allows you to place multiple switches in a queue and then activate them simultaneously with one touch of this button
- Consists of a LOCK button to prevent tampering with the front panel
- Automatically detects connected input signals (respective button illuminates)

Control the **VP-8x8** using the front panel buttons, or remotely via:

- RS-485 or RS-232 serial commands transmitted by a touch screen system, PC, or other serial controller
- The Kramer Infra-Red remote control transmitter
- Ethernet

The **VP-8x8** is dependable, rugged, and fits into one vertical space (1U) of a standard 19" professional rack². To achieve the best performance:

- Connect only good quality connection cables, thus avoiding interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Avoid interference from neighboring electrical appliances that may adversely influence signal quality and position your Kramer **VP-8x8** away from moisture, excessive sunlight and dust

¹ In increments of 0.5sec

² The RGBHV signals are connected on HD15 pin connectors to reduce enclosure size

3.1 Terminology Used in this User Manual

Table 1 defines some terms that are used in this user manual:

Table 1: Terminology Used in this User Manual

Term	Definition
802.3	The standard specification for ETHERNET that is maintained by the Institute of Electrical and Electronics Engineers (IEEE).
Dynamic Host Configuration Protocol (DHCP)	Allows the network administrator to distribute IP addresses from a central point and automatically send a new IP address when an Ethernet point is plugged into a different network location.
Gateway	A network position serving as an entry to another network. On the Internet, a node or stopping point can be either a gateway node or a host (end-point) node.
IP Address	A 32-binary digit number that identifies each sender or receiver (within a network via a particular server or workstation) of data (HTML pages or e-mails) that is sent in packets across the Internet. Every device connected to an IP network must have a unique IP address. This address is used to reference the specific unit.
Local Area Network (LAN)	Computers sharing a common communications line or wireless link, which often share a server within a defined geographic area.
Media Access Control (MAC) Address	A computer's unique hardware number (or address) in a LAN or other network. On an Ethernet LAN, the (MAC) address is identical to the Ethernet address.
Transmission Control Protocol/Internet Protocol (TCP/IP)	The basic communication language or protocol of the Internet that breaks the message into appropriately sized packets for the network, and can be used as a communications protocol in an intranet or an extranet.

4 Your VP-8x8 8x8 VGA / UXGA Matrix Switcher

Figure 1, Table 2 and Table 3 define the **VP-8x8 8x8 VGA / UXGA Matrix Switcher**. Figure 2 illustrates the underside of the **VP-8x8** unit, and Table 4 defines the underside features.

Your VP-8x8 8x8 VGA / UXGA Matrix Switcher




Figure 1: VP-8x8 8x8 VGA / UXGA Matrix Switcher – Front and Rear View




Figure 2: VP-8x8 8x8 VGA / UXGA Matrix Switcher – Underside View

Table 2: Front Panel VP-8x8 8x8 VGA / UXGA Matrix Switcher Features

#	Feature	Function
1	IR Receiver	The red LED is illuminated when receiving signals from the Infra-red remote control transmitter
2	POWER Switch	Illuminated switch for turning the unit ON or OFF
3	IN SELECTOR Buttons	Select the input to switch to the output. When a signal is detected, the input button illuminates in green
4	OUT SELECTOR Buttons	Select the output to which the input is switched
5	ALL Button	Pressing ALL followed by an INPUT button, connects that input to all outputs ¹
6	OFF Button	Press an OUT SELECTOR button and then an OFF button to disconnect that output from the inputs Press the ALL button and then the OFF button to disconnect all the outputs
7	TAKE Button	Pressing TAKE toggles the mode between the Confirm mode ² and the At Once mode (user confirmation per action is unnecessary)
8	STO (Store) Button	Pressing STO followed by an input/output button stores the current setting ³
9	RCL (Recall) Button	Pressing the RCL button and the corresponding IN/OUT button recalls a setup from the non-volatile memory. The stored status blinks. Pressing a different IN/OUT button lets you view ⁴ another setup. After making your choice, pressing the RCL button again implements the new status
10	LOCK Button	Disengages the front panel switches
11	STATUS 7-segment Display	Displays the selected input switched to the output (marked above each input) ⁵

Table 3: Rear Panel VP-8x8 8x8 VGA / UXGA Matrix Switcher Features

#	Feature	Function
12	HD15F INPUT Connectors	Connect to the video sources (from 1 to 8)
13	HD15F OUTPUT Connectors	Connect to the output acceptor (from 1 to 8)
14	FLASH PROG Button	Push in for "Program" to upgrade to the latest Kramer firmware (see section 7), or release for Normal (the factory default) ⁶
15	RS-232 DB 9F Port	Connects to the PC or the Remote Controller
16	DELAY and SETUP Dipswitches	Dipswitches for setup of the unit (DELAY dips 1, 2, 3 are for setting the delay time; SETUP dips 1, 2, 3, 4 are for setting machine #; 8 is for RS-485 Termination)
17	ETHERNET Connector	Connects to the PC or other Serial Controller through computer networking
18	RS-485 Terminal Block Port	Pin G is for Ground connection; Pins B (-) and A (+) are for RS-485
19	Power Connector with Fuse	AC connector enabling power supply to the unit

Table 4: VP-8x8 Underside Panel Features

#	Feature	Function
1	RESET FOR PROGRAM Button	Press to reset unit prior to firmware upgrade (see section 7.3)

1 For example, press ALL and then Input button # 2 to connect input # 2 to all the outputs

2 When in the Confirm mode, the TAKE button illuminates

3 For example, press STO and then the Output button # 3 to store in Setup # 3

4 Only view, nothing is implemented at this stage

5 Also displays the number of IN and OUT ports, the firmware version number, and the MACHINE # Refer to section 6.1

6 The FLASH PROG "Reset" button is located on the underside of the unit

5 Connecting the VP-8x8

This section describes how to:

- Connect the **VP-8x8** rear panel (see section 5.1)
- Connect the **VP-8x8** to a controlling device via RS-232 (see section 5.2), RS-485 (see section 5.3) and/or the Ethernet (see section 5.4)
- Set the dipswitches (see section 5.5)
- Connect several **VP-8x8** machines (see section 5.6)

5.1 Connecting the VP-8x8 Rear Panel

To connect the **VP-8x8**, do the following¹:

1. Connect up to 8 VGA/UXGA computer graphics sources to the input connectors (see the illustration in Figure 3).
2. Connect² the 8 output connectors to up to 8 VGA/UXGA video acceptors³.
3. Set the dipswitches (see section 5.4).
4. Connect a PC and/or controller (if required) to the RS-232 port (see section 5.2) and/or RS-485 port (see section 5.3).
5. Connect the power cord⁴.

1 Switch OFF the power on each device before connecting it to your VP-8x8. After connecting your VP-8x8, switch on its power and then switch on the power on each device. DO NOT push in the rear panel Flash Program "Program" button (item 9 in Table 3) and DO NOT push in the underside Flash Program "Reset" button. These are only used for upgrading to the latest Kramer firmware (see section 7)

2 When less than eight outputs are required, connect only those outputs of the VP-8x8 that are required, and leave the other outputs unconnected.

3 Displays or projectors.

4 We recommend that you use only the power cord that is supplied with this machine.




Figure 3: Connecting the VP-8x8 8x8 VGA / UXGA Matrix Switcher

5.2 Controlling via RS-232 (for example, using a PC)

To connect a PC to the **VP-8x8** unit, using the Null-modem adapter provided *with* the machine (recommended):

- Connect the RS-232 DB9 rear panel port on the Master **VP-8x8** unit to the Null-modem adapter and connect the Null-modem adapter with a 9-wire flat cable to the RS-232 DB9 port on your PC

To connect a PC to the **VP-8x8** unit, *without* using a Null-modem adapter:

- Connect the RS-232 DB9 port on your PC to the RS-232 DB9 rear panel port on the Master **VP-8x8** unit, as Figure 4 illustrates (depending on whether the PC has a 9-pin or 25-pin connector)




Figure 4: Connecting a PC without using a Null-modem Adapter

5.3 Controlling via RS-485

You can control a **VP-8x8** unit via an RS-485 controller, for example, a PC (equipped with an RS-485 interface) or a Master Programmable Remote Control system such as the Kramer **RC-3000**¹.

To connect an **RC-3000** to a **VP-8x8** unit (see Figure 5):

1. Connect the RS-485 terminal block port on the **RC-3000** to the RS-485 port on the **VP-8x8** unit, as follows:
 - Connect the “A” (+) PIN on the RS-485 rear panel port of the **RC-3000** to the “A” (+) PIN on the RS-485 rear panel port of the **VP-8x8** unit
 - Connect the “B” (-) PIN on the RS-485 rear panel port of the **RC-3000** to the “B” (-) PIN on the RS-485 rear panel port of the **VP-8x8** unit
 - If shielded twisted pair cable is used, the shield may be connected to the “G” (Ground) PIN on one of the units (for example, on the **RC-3000**)
2. Set the **VP-8x8** unit as Machine # 1, according to Table 9 (that is, DIP 1, DIP 2, DIP 3, and DIP 4 OFF), and set the other dipswitches on the **VP-8x8** unit, as follows:
 - Set DIP 5, DIP 6, and DIP 7 OFF
 - Set DIP 8 ON (for RS-485 Line Termination with 120Ω)




Figure 5: Controlling via RS-485 (for example, using an RC-3000)

¹ Previously known as the VS-3000

5.4 Control Configuration via the Ethernet Port

You can connect the **VP-8x8** via the Ethernet, using a crossover cable (see section 5.4.1) for direct connection to the PC or a straight through cable (see section 5.4.2) for connection via a network hub or network router¹.


5.4.1 Connecting the ETHERNET Port directly to a PC (Crossover Cable)

You can connect the Ethernet port of the **VP-8x8** to the Ethernet port on your PC, via a crossover cable with RJ-45 connectors, as Table 5 and Figure 6 define.

Figure 6: RJ-45 PINOUT

Table 5: Crossover Cable RJ-45 PINOUT

EIA /TIA 568A Side 1		EIA /TIA 568B Side 2	
PIN	Wire Color	PIN	Wire Color
1	White-orange	1	White-green
2	Orange	2	Green
3	White-green	3	White-orange
4	Blue	4	Blue
5	White-blue	5	White-blue
6	Green	6	Orange
7	White-brown	7	White-brown
8	Brown	8	Brown
Pair 1 4 and 5		Pair 1 4 and 5	
Pair 2 1 and 2		Pair 2 3 and 6	
Pair 3 3 and 6		Pair 3 1 and 2	
Pair 4 7 and 8		Pair 4 7 and 8	



This type of connection is recommended for identification of the factory default IP Address of the **VP-8x8** during the initial configuration

After connecting the Ethernet port, configure your PC as follows:

1. Right-click the My Network Places icon on your desktop.
2. Select **Properties**.

¹ After connecting the Ethernet port, you have to install and configure your Ethernet Port and also install the COM Port Redirector. For detailed instructions, see the "Ethernet Configuration (Lantronix) guide.pdf" file in the technical support section on our Web site: <http://www.kramerelectronics.com>

3. Right-click Local Area Connection Properties.
4. Select **Properties**.
The Local Area Connection Properties window appears.
5. Select the Internet Protocol (TCP/IP) and click the **Properties** Button (see Figure 7).




Figure 7: Local Area Connection Properties Window

6. Select Use the following IP Address, and fill in the details as shown in Figure 8.
7. Click **OK**.




Figure 8: Internet Protocol (TCP/IP) Properties Window

5.4.2 Connecting the ETHERNET Port via a Network Hub (Straight-Through Cable)

You can connect the Ethernet port of the **VP-8x8** to the Ethernet port on a network hub or network router, via a straight-through cable with RJ-45 connectors, as Table 6 defines:

Table 6: Straight-through Cable RJ-45 PINOUT

Side 1		Side 2	
PIN	Wire Color	PIN	Wire Color
1	White-orange	1	White-orange
2	Orange	2	Orange
3	White-green	3	White-green
4	Blue	4	Blue
5	White-blue	5	White-blue
6	Green	6	Green
7	White-brown	7	White-brown
8	Brown	8	Brown

5.4.3 Control Configuration via the Ethernet Port

To control several units via the Ethernet, connect the Master unit (MACH NO. 1) via the Ethernet port to the LAN port of your PC. Use your PC initially to configure the settings (see section 5.4).

5.5 Setting the Dipswitches

By default, all dipswitches are set to OFF. Figure 9 illustrates the **VP-8x8** dipswitches:




Figure 9: VP-8x8 Dipswitches

Table 7: Dipswitch Settings

DIPS	Function	Description
1, 2, 3	DELAY	Determines switching delay time
4	Reserved	Set to OFF
1, 2, 3, 4	Machine #	Determines the number of the machine in the sequence
5, 6, 7	Reserved	Set to OFF
8	RS-485 TERM	ON for RS-485 Line Termination with 120Ω; OFF for no RS-485 Line Termination

5.5.1 Setting the Delay

You can achieve clean transitions when switching between non-genlocked sources by setting the delay time—ranging from 0sec to 3.5sec¹—via the DELAY dipswitches, as Table 8 defines. The **VP-8x8** unit is shipped (its factory default state) with no delay, that is, the DELAY dipswitches are set up for a 0sec delay.

Table 8: DELAY Dipswitch Settings

sec	DIP 1	DIP 2	DIP 3
0	OFF	OFF	OFF
0.5	OFF	OFF	ON
1.0	OFF	ON	OFF
1.5	OFF	ON	ON
2.0	ON	OFF	OFF
2.5	ON	OFF	ON
3.0	ON	ON	OFF
3.5	ON	ON	ON

¹ In increments of 0.5sec

5.5.2 Setting the Machine # Dipswitches

The Machine # determines the position of a **VP-8x8** unit, specifying which **VP-8x8** unit is being controlled when several **VP-8x8** units connect to a PC or serial controller. Set the Machine # on a **VP-8x8** unit via Setup DIPS 1, 2, 3 and 4, according to Table 9.

When using a standalone **VP-8x8** unit, set the Machine # to 1. When connecting more than one **VP-8x8** unit, set the first machine (the Master) that is closest to the PC, as Machine # 1 (dipswitches are set to OFF).

Table 9: Machine # Dipswitch Settings

Mach. #	DIP 1	DIP 2	DIP 3	DIP 4
1	OFF	OFF	OFF	OFF
2	OFF	OFF	OFF	ON
3	OFF	OFF	ON	OFF
4	OFF	OFF	ON	ON
5	OFF	ON	OFF	OFF
6	OFF	ON	OFF	ON
7	OFF	ON	ON	OFF
8	OFF	ON	ON	ON

Mach. #	DIP 1	DIP 2	DIP 3	DIP 4
9	ON	OFF	OFF	OFF
10	ON	OFF	OFF	ON
11	ON	OFF	ON	OFF
12	ON	OFF	ON	ON
13	ON	ON	OFF	OFF
14	ON	ON	OFF	ON
15	ON	ON	ON	OFF
16	ON	ON	ON	ON

5.6 Cascading Machines

You can cascade up to 16 **VP-8x8** units with control from a PC or serial controller (see Figure 10).

To cascade up to 16 individual **VP-8x8** units via RS-485, do the following:

1. Connect the VGA/UXGA sources and acceptors, as section 5.1 describes.
2. Connect the RS-232 port¹ onto the first **VP-8x8** unit to the PC using the Null-modem adapter provided with the machine (recommended), as section 5.2 describes.
3. Connect the RS-485 terminal block port on the first unit to the RS-485 port on the second **VP-8x8** unit and so on, connecting all the RS-485 ports.
4. Set the dipswitches, as section 5.4 describes:
 - Set the first **VP-8x8** unit as Machine # 1 and the following 15 **VP-8x8** units as Machine # 2 to Machine # 16, according to Table 9
 - Set DIP 8 ON on the first and last **VP-8x8** units (terminating the RS-485 line at 120Ω). Set DIP 8 OFF on the other **VP-8x8** units
 - Set DIP 5, DIP 6 and DIP 7 OFF on all **VP-8x8** units

¹ Alternatively, the RS-485 port could be used for PC control (instead of RS-232)




Figure 10: Control Configuration via RS-232 and RS-485

6 Operating the VP-8x8



You can operate your **VP-8x8** via:

- The front panel buttons
- RS-232/RS-485 serial commands transmitted by a touch screen system, PC, or other serial controller
- The Kramer **RC-IR1** Infra-Red Remote Control Transmitter
- The Ethernet

6.1 Displaying Unit Characteristics

The STATUS 7-segment display shows two sets of information, as defined in Table 10:

Table 10: STATUS 7-segment Display

The STATUS Display	Shows:	When:
 <p>First Display</p> <p>STATUS</p> <p>OUTPUT 1 2 3 4 5 6 7 8</p> <p>INPUT 1.0 01</p> <p>Firmware version #</p> <p>Machine #</p>	<p>Unit characteristics:</p> <ul style="list-style-type: none"> • Firmware version • Machine number 	<ul style="list-style-type: none"> • Immediately (and automatically) after switching on the power • When simultaneously pressing, for 3 seconds, the 3 "IN" buttons 1, 2 and 3
 <p>Second Display</p> <p>STATUS</p> <p>OUTPUT 1 2 3 4 5 6 7 8</p> <p>INPUT 6 8</p> <p>input 6 is connected to output 5</p> <p>input 8 is connected to output 8</p>	<p>Normal display: Inputs switched to the outputs</p>	<p>During normal operation, appears a few seconds after the first display¹</p>

6.2 Confirming Settings

You can choose to work in the At Once or the Confirm mode.

In the At Once mode (TAKE button is dim):

- Pressing an OUT-IN combination implements the switch immediately
- You save time as execution is immediate and actions require no user confirmation
- No protection is offered against changing an action in error

In the Confirm mode (TAKE button is lit):

- You can key-in several actions and then confirm them by pressing the TAKE button, to simultaneously activate the multiple switches
- Every action requires user confirmation, protecting against erroneous switching
- Execution is delayed² until the user confirms the action

¹ The "First Display" appears initially, followed a few seconds later by the "Second Display"

² Failure to press the TAKE button within one minute (the Timeout) will abort the action

6.2.1 Toggling between the At Once and Confirm Modes

To toggle between the At Once and Confirm modes, do the following:

1. Press the dim TAKE button to toggle from the At Once mode (in which the TAKE button is dim) to the Confirm mode (in which the TAKE button illuminates).
Actions now require user confirmation and the TAKE button illuminates.
2. Press the illuminated TAKE button to toggle from the Confirm mode back to the At Once mode.
Actions no longer require user confirmation and the TAKE button no longer illuminates.

6.2.2 Confirming a Switching Action

To confirm a switching action (in the Confirm mode), do the following:

1. Press an OUT-IN combination.
The corresponding 7-segment Display blinks. The TAKE button also blinks.
2. Press the blinking TAKE button to confirm the action.
The corresponding 7-segment Display no longer blinks. The TAKE button illuminates.

To confirm several actions (in the Confirm mode), do the following:

1. Press each OUT-IN combination in sequence.
The corresponding 7-segment Display blinks. The TAKE button also blinks.
2. Press the blinking TAKE button to confirm all the actions.
The corresponding 7-segment Display no longer blinks. The TAKE button illuminates.

6.3 Storing/Recalling Input/Output Configurations

You can store and recall up to 16 input/output configurations using the 8 input buttons and the 8 output buttons, as Figure 11 illustrates:




Figure 11: Storing and Recalling using the Input/Output Buttons

6.3.1 Storing an Input/Output Configuration

To store the current status in memory, do the following:

1. Press the STO button.
The STO button blinks.
2. Press one of the 16 INPUT/OUTPUT buttons (this will be the setup # in which the current status is stored). If in the Confirm mode, press the blinking TAKE button to confirm the action.
The memory stores the data at that reference.

6.3.2 Recalling an Input/Output Configuration

To recall an input/output configuration, do the following:

1. Press the RCL button.
The RCL button blinks.
2. Press the appropriate INPUT/OUTPUT button (the button # corresponding to the setup #). If in the Confirm mode, that setup configuration will blink in the 7-segment Display, together with the RCL button and the TAKE button, and will only be implemented after pressing the TAKE button.
The memory recalls the stored data from that reference.

Tip: If you cannot remember which of the 16 input/output configurations is the one that you want, set the **VP-8x8** to the Confirm mode and manually scan all the input/output configurations until you locate it.

6.3.3 Deleting an Input/Output Configuration

To delete an input/output configuration, do the following:

1. Press the STO and RCL buttons simultaneously.
Both the STO and RCL buttons blink.
2. Press the appropriate INPUT/OUTPUT button.
This erases that specific input/output configuration from the memory, leaving it empty and available¹.

¹ Storing a new configuration over a previous configuration (without deleting it first) replaces the previous configuration

6.4 Locking the Front Panel

To prevent changing the settings accidentally or tampering with the unit via the front panel buttons, lock¹ your **VP-8x8**. Unlocking releases the protection mechanism.

To lock the **VP-8x8**:

- Press the LOCK button for more than two seconds, until the LOCK button is illuminated
The front panel is locked. Pressing a button will have no effect other than causing the LOCK button to blink²

To unlock the **VP-8x8**:

- Press the illuminated LOCK button for more than two seconds, until the LOCK button is no longer illuminated
The front panel unlocks

¹ Nevertheless, even though the front panel is locked you can still operate via RS-232 or RS-485, as well as via the Kramer RC-IR1 Infra-Red Remote Control Transmitter

² Warning that you need to unlock to regain control via the front panel

7 Flash Memory Upgrade

The **VP-8x8** firmware is located in FLASH memory, which lets you upgrade to the latest Kramer firmware version in minutes! The process involves:

- Downloading from the Internet (see section 7.1)
- Connecting the PC to the RS-232 port (see section 7.2)
- Upgrading Firmware (see section 7.3)

7.1 Downloading from the Internet

You can download the up-to-date file from the Internet. To do so:

1. Go to our Web site at [www.kramer.com](#) and download the file: "FLIP_VP8x8.zip" from the Technical Support section.
2. Extract the file: "*FLIP_VP8x8.zip*" to a folder (for example, C:\Program Files\Kramer Flash).
3. Create a shortcut on your desktop to the file: "*FLIP.EXE*".

7.2 Connecting the PC to the RS-232 Port

Before installing the latest Kramer firmware version on a **VP-8x8** unit, do the following:

1. Connect the RS-232 DB9 rear panel port on the **VP-8x8** unit to the Null-modem adapter and connect the Null-modem adapter with a 9-wire flat cable to the RS-232 DB9 COM port on your PC (see section 5.2).
2. On the rear panel, push in the FLASH PROG button (to program), using a screwdriver.
3. Connect the power on the **VP-8x8** unit and switch it ON.
4. On the underside panel, push in the RESET FOR PROGRAM button (see Figure 2), using a screwdriver.

7.3 Upgrading Firmware

Follow these steps to upgrade the firmware:

1. Double click the desktop icon: "*Shortcut to FLIP.EXE*".
The Splash screen appears as follows:




Figure 12: Splash Screen

2. After a few seconds, the Splash screen is replaced by the “Atmel Flip” window:




Figure 13: Atmel Flip Window

3. Press the keyboard shortcut key *F2* (or select the “Select” command from the *Device* menu, or press the integrated circuit icon in the upper right corner of the window).
The “Device Selection” window appears:




Figure 14: Device Selection Window

4. Click the button next to the name of the device and select from the list:
AT89C51RD2:




Figure 15: Selecting the Device from the Selection Window

5. Click OK and select "Load Hex" from the File menu.




Figure 16: Loading the Hex

6. The Open File window opens. Select the correct HEX file that contains the updated version of the firmware for **VP-8x8** (for example **8x8M_V1p2.hex**) and click Open.
7. Press the keyboard shortcut key *F3* (or select the “*Communication / RS232*” command from the *Settings* menu, or press the keys: *Alt SCR*). The “*RS232*” window appears. Change the COM port according to the configuration of your computer and select the 9600 baud rate:




Figure 17: RS-232 Window

8. Click Connect.
In the “*Atmel – Flip*” window, in the *Operations Flow* column, the *Run* button is active, and the name of the chip appears as the name of the third column: *AT89C51RD2*.

Verify that in the *Buffer Information* column, the “*HEX File: VP8x8.hex*” appears.




Figure 18: Atmel – Isp Window (Connected)

9. Click *Run*.
After each stage of the operation is completed, the check-box for that stage becomes colored green¹.
When the operation is completed, all 4 check-boxes will be colored green and the status bar message: *Memory Verify Pass* appears²:

¹ See also the blue progress indicator on the status bar

² If an error message: “Not Finished” shows, click Run again



Figure 19: Atmel Flip Window (Operation Completed)

10. Close the “Atmel – Flip” window.
11. Disconnect the power on the **VP-8x8**.
12. Disconnect the RS-232 rear panel port on the **VP-8x8** unit from the Null-modem adapter.
13. Release FLASH PROG button on rear panel (Figure 1).
14. Connect the power to the **VP-8x8**.
Upon initialization, the new **VP-8x8** software version shows in the INPUT STATUS 7-segment Display (see Table 10).

8 Technical Specifications

Table 11 includes the technical specifications:

Table 11: Technical Specifications¹ of the VP-8x8 8x8 Video Matrix Switcher

INPUTS:	8 VGA on HD15 connectors (VGA through UXGA)
OUTPUTS:	8 VGA on HD15 connectors (VGA through UXGA)
MAX. OUTPUT LEVEL:	1.5Vpp
BANDWIDTH (-3dB):	400MHz
DIFF. GAIN:	0.04%
DIFF. PHASE:	0.04 Deg.
K-FACTOR:	<0.05%
S/N RATIO:	75dB
CROSSTALK (all hostile):	-53dB
CONTROLS:	22 front panel buttons, RS-232, RS-485, Ethernet
COUPLING:	DC
POWER SOURCE:	100-264 VAC, 50/60 Hz, 23VA
D MENSIONS:	19-inch (W), 7-inch (D) 1U (H) rack-mountable
WEIGHT:	2.7 kg (6 lbs.) approx.
ACCESSORIES:	Power cord, Null modem adapter, Windows®-based Kramer control software, Infra-red remote control transmitter

¹ Specifications are subject to change without notice

9 Table of Hex Codes for Serial Communication

Table 12 lists the Hex values for a single machine (*MACHINE # 1*):

Table 12: VP-8x8 Hex Codes for Switching via RS-232/RS-485

		Switching Video Channels							
		OUT 1	OUT 2	OUT 3	OUT 4	OUT 5	OUT 6	OUT 7	OUT 8
IN 1	01	01	01	01	01	01	01	01	01
	81	81	81	81	81	81	81	81	81
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 2	01	01	01	01	01	01	01	01	01
	82	82	82	82	82	82	82	82	82
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 3	01	01	01	01	01	01	01	01	01
	83	83	83	83	83	83	83	83	83
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 4	01	01	01	01	01	01	01	01	01
	84	84	84	84	84	84	84	84	84
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 5	01	01	01	01	01	01	01	01	01
	85	85	85	85	85	85	85	85	85
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 6	01	01	01	01	01	01	01	01	01
	86	86	86	86	86	86	86	86	86
	81	82	83	84	81	82	83	84	
	81	81	81	81	81	81	81	81	81
IN 7	01	01	01	01	01	01	01	01	01
	87	87	87	87	87	87	87	87	87
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81
IN 8	01	01	01	01	01	01	01	01	01
	88	88	88	88	88	88	88	88	88
	81	82	83	84	85	86	87	88	
	81	81	81	81	81	81	81	81	81

10 Kramer Protocol 2000¹

The **VP-8x8** is compatible with Kramer's Protocol 2000 (version 0.46) (below). This RS-232/RS-485 communication protocol uses four bytes of information as defined below. For RS-232, a null-modem connection between the machine and controller is used. The default data rate is 9600 baud, with no parity, 8 data bits and 1 stop bit.

Table 13: Protocol Definitions

MSB								LSB	
		DESTINATION		INSTRUCTION					
0	D	N6	N4	N3	N2	N1	N0		
7	8	5	4	3	2	1	0		
1st byte									
		INPUT							
1	6	I5	I4	I3	I2	I1	I0		
7	8	5	4	3	2	1	0		
2nd byte									
		OUTPUT							
1	O6	O5	O4	O3	O2	O1	O0		
7	8	5	4	3	2	1	0		
3rd byte									
		MACHINE NUMBER							
1	OVR	X	M4	M3	M2	M1	M0		
7	8	5	4	3	2	1	0		
4th byte									

1st BYTE: Bit 7 – Defined as 0

D – “DESTINATION”: 0 - for sending information to the switchers (from the PC);

1 - for sending to the PC (from the switcher)

N5 – N0 – “INSTRUCTION”

The function that is to be performed by the switcher(s) is defined by the INSTRUCTION (6 bits). Similarly, if a function is performed via the machine's keyboard, then these bits are set with the INSTRUCTION NO., which was performed. The instruction codes are defined according to the table below (INSTRUCTION NO. is the value to be set for N5 – N0).

2nd BYTE: Bit 7 – Defined as 1
I6 – I0 – “INPUT”

When switching (ie. instruction codes 1 and 2), the INPUT (7 bits) is set as the input number which is to be switched. Similarly, if switching is done via the machine's front-panel, then these bits are set with the INPUT NUMBER which was switched. For other operations, these bits are defined according to the table.

3rd BYTE: Bit 7 – Defined as 1
O6 – O0 – “OUTPUT”

When switching (ie. instruction codes 1 and 2), the OUTPUT (7 bits) is set as the output number which is to be switched. Similarly, if switching is done via the machine's front-panel, then these bits are set with the OUTPUT NUMBER which was switched. For other operations, these bits are defined according to the table.

4th BYTE: Bit 7 – Defined as 1
Bit 5 – Don't care
OVR – Machine number override
M4 – M0 – MACHINE NUMBER

Used to address machines in a system via their machine numbers. When several machines are controlled from a single serial port, they are usually configured together with each machine having an individual machine number. If the OVR bit is set to 1, then all machine numbers will accept (implement) the command, and only the addressed machine will reply.

¹ You can download our user-friendly “Software for Calculating Hex Codes for Protocol 2000” from the technical support section on our Web site at: <http://www.kramerelectronics.com>

Kramer Protocol 2000

For a single machine controlled via the serial port, always set M4 M0 = 00001, and make sure that the machine itself is configured as MACHINE NUMBER = 1

Table 14: Instruction Codes for Protocol 2000

Note: All values in the table are decimal, unless otherwise stated

INSTRUCTION		DEFINITION FOR SPECIFIC INSTRUCTION		NOTE
#	DESCRIPTION	INPUT	OUTPUT	
0	RESET VIDEO	0	0	1
1	SWITCH VIDEO	Set equal to video input which is to be switched (0 = disconnect)	Set equal to video output which is to be switched (0 = to all the outputs)	2, 15
2	SWITCH AUDIO	Set equal to audio input which is to be switched (0 = disconnect)	Set equal to audio output which is to be switched (0 = to all the outputs)	2
3	STORE VIDEO STATUS	Set as SETUP #	0 - to store 1 - to delete	2, 3, 15
4	RECALL VIDEO STATUS	Set as SETUP #	0	2, 3, 15
5	REQUEST STATUS OF A VIDEO OUTPUT	Set as SETUP #	Equal to output number whose status is reqd	4, 3
6	REQUEST STATUS OF AN AUDIO OUTPUT	Set as SETUP #	Equal to output number whose status is reqd	4, 3
7	VIS SOURCE	Set as input # when OUTPUT byte = 6; OR set as output # when OUTPUT byte = 7; OR set as blank period (in steps of 25ms) when OUTPUT byte = 32; OR set = 0. ****	0 - No VIS (immediate) 1 - Input # 1 2 - External digital sync 3 - External analog sync 4 - Dynamic sync 5 - Inter-machine sync 6 - Input # (NPUT byte) 7 - Output # (NPUT byte) 8 - User-defined sync 32 - RGBHV seamless switching 64 - Set for delayed switch 65 - Execute delayed switch 66 - Cancel delayed switch setting	2, 5, 17, 18
8	BREAKAWAY SETTING	0	0 - audio-follow-video 1 - audio breakaway	2
		1	0 - FOLLOW mode 1 - Normal mode	15
8	VIDEO / AUDIO TYPE SETTING	0 - for video	0 - CV 4 - SDI 1 - YC 5 - CV+YC 2 - YUV 6 - VGA scaler 3 - RGBS 7 - DVI	2
		1 - for audio	O0=0 - Unbalanced audio O0=1 - Balanced audio O1=0 - Digital audio O1=1 - Analog audio O4=0, O3=0, O2=0-Mono O4=0, O3=0, O2=1-Stereo	
		2 - for VGA and DVI	1 - 640X480 2 - 800X600 3 - 1024X768	
10	REQUEST VIS SETTING	Set as SETUP #, or set to 126 or 127 to request if machine has this function	0 - VIS source 1 - Input # or output # of source 2 - Vertical sync freq (Hz)	3, 4, 6, 7
11	REQUEST BREAKAWAY SETTING	Set as SETUP #, or set to 126 or 127 to request if machine has this function	0 - Request audio breakaway setting 1 - Request "FOLLOW" setting	3, 4, 6, 15
12	REQUEST VIDEO / AUDIO TYPE SETTING	Set as SETUP #, or set to 126 or 127 to request if machine has this function	0 - for video 1 - for audio 2 - for VGA	3, 4, 8
13	SET HIGHEST MACHINE ADDRESS	0 - for video 1 - for audio	Set equal to highest machine address	2
14	REQUEST HIGHEST MACHINE ADDRESS	0 - for video 1 - for audio	0	4

INSTRUCTION		DEFINITION FOR SPECIFIC INSTRUCTION		NOTE
#	DESCRIPTION	INPUT	OUTPUT	
15	REQUEST WHETHER SETUP IS DEFINED / VALID INPUT IS DETECTED	SETUP # or Input #	0 - for checking if setup is defined 1 - for checking if input is valid	8
16	ERROR / BUSY	For invalid / valid input (i.e. OUTPUT byte = 4 or OUTPUT byte = 5), this byte is set as the input #	0 - error 1 - invalid instruction 2 - out of range 3 - machine busy 4 - invalid input 5 - valid input	9, 25
17	RESERVED	----	----	10
18	RESET AUDIO	0	0	1
19	STORE AUDIO STATUS	Set as SETUP #	0 - to store 1 - to delete	2, 3
20	RECALL AUDIO STATUS	Set as SETUP #	0	2, 3
21	SET VIDEO PARAMETER	Equal to input / output number whose video parameter is to be set (0 = all)	Set as parameter value	2, 11, 24
22	SET AUDIO PARAMETER	Equal to input / output number whose gain is to be set (0 = all)	Set as parameter value	2, 11, 24
23	INCREASE / DECREASE VIDEO PARAMETER	Equal to input / output number whose video parameter is to be increased / decreased (0 = all)	0 - increase video gain 1 - decrease video gain 2 - increase contrast 3 - decrease contrast 4 - increase brightness 5 - decrease brightness 6 - increase colour 7 - decrease colour 8 - increase hue 9 - decrease hue 16 - increase H-phase 17 - decrease H-phase 18 - increase V-position 19 - decrease V-position	24
24	INCREASE / DECREASE AUDIO PARAMETER	Equal to input / output number whose parameter is to be increased / decreased (0 = all)	0 - increase output 1 - decrease output 2 - increase left output 3 - decrease left output 4 - increase right output 5 - decrease right output 6 - increase input 7 - decrease input 8 - increase left input 9 - decrease left input 10 - increase right input 11 - decrease right input	24
25	REQUEST AUDIO PARAMETER	Equal to input / output number whose parameter is requested	0	6, 24
26	REQUEST VIDEO PARAMETER	Equal to input / output number whose video parameter is requested	0	6, 24
30	LOCK FRONT PANEL	0 - Panel unlocked 1 - Panel locked	0	2
31	REQUEST WHETHER PANEL IS LOCKED	0	0	16
32 to 35	RESERVED	----	----	10
40	DIRECT MEMORY SAVE	Memory address	Data	20

INSTRUCTION		DEFINITION FOR SPECIFIC INSTRUCTION		NOTE
#	DESCRIPTION	INPUT	OUTPUT	
42	AUDIO PARAMETER SETTINGS FOR INSTRUCTIONS 22, 24, 25	INPUT Bit: 10 - 0=input, 1=output 11 - Left 12 - Right	0 - Gain 1 - Bass 2 - Treble 3 - Midrange	24
43	VIDEO PARAMETER SETTINGS FOR INSTRUCTIONS 21, 23, 26	1 - Input 2 - Output	0 - video gain 1 - contrast 2 - brightness 3 - colour 4 - hue 5 - H-phase 6 - V-position	24
56	CHANGE TO ASCII	0	1 - SYS protocol 2 - Generic protocol	19
57	SET AUTO-SAVE	13 - no save 14 - auto-save	0	12, 2
58	EXECUTE LOADED DATA	Set as 0, or as SETUP #	1-Take 2-Cancel	22, 3
59	LOAD VIDEO DATA	Set equal to video input (0 = disconnect) ----- (127 = load SETUP #)	Set equal to video output (0 = to all the outputs) ----- or SETUP #	22, 23
60	LOAD AUDIO DATA	Set equal to audio input (0 = disconnect) ----- (127 = load SETUP #)	Set equal to audio output (0 = to all the outputs) ----- or SETUP #	22, 23
61	IDENTIFY MACHINE	1 - video machine name 2 - audio machine name 3 - video software version 4 - audio software version 5 - RS422 controller name 6 - RS422 controller version 7 - remote control name 8 - remote software version 9 - Protocol 2000 revision	0 - Request first 4 digits 1 - Request first suffix 2 - Request second suffix 3 - Request third suffix 10 - Request first prefix 11 - Request second prefix 12 - Request third prefix	13
62	DEFINE MACHINE	1 - number of inputs 2 - number of outputs 3 - number of setups	1 - for video 2 - for audio 3 - for SDI 4 - for remote panel 5 - for RS-422 controller	14
63	EXTENDED DATA	7 MSBs for INPUT data	7 MSBs for OUTPUT data	20

NOTES on the above table:

NOTE 1 - When the master switcher is reset, (e.g. when it is turned on), the reset code is sent to the PC. If this code is sent to the switchers, it will reset according to the present power-down settings.

NOTE 2 - These are bi-directional definitions. That is, if the switcher receives the code, it will perform the instruction; and if the instruction is performed (due to a keystroke operation on the front panel), then these codes are sent. For example, if the HEX code

01 85 88 83
was sent from the PC, then the switcher (machine 3) will switch input 5 to output 8. If the user switched input 1 to output 7 via the front panel keypad, then the switcher will send HEX codes:

41 81 87 83

to the PC.

When the PC sends one of the commands in this group to the switcher, then, if the instruction is valid, the switcher replies by sending to the PC the same four bytes that it was sent (except for the first byte, where the DESTINATION bit is set high).

NOTE 3 - SETUP # 0 is the present setting. SETUP # 1 and higher are the settings saved in the switcher's memory, (i.e. those used for Store and Recall).

NOTE 4 - The reply to a "REQUEST" instruction is as follows: the same instruction and INPUT codes as were sent are returned, and the OUTPUT is assigned the value of the requested parameter. The replies to instructions 10 and 11 are as per the definitions in instructions 7 and 8 respectively. For example, if the present status of machine number 5 is breakaway setting, then the reply to the HEX code

0B 80 80 85

would be HEX codes

4B 80 81 85



NOTE 5 – For the OUTPUT byte set as 6, the VIS source is the input selected using the OUTPUT byte. Similarly, for the OUTPUT byte set as 7, the VIS source is the output selected using the OUTPUT byte. Note also, that on some machines the sync source is not software selectable, but is selected using switches, jumpers, etc!

NOTE 6 – If INPUT is set to 127 for these instructions, then, if the function is defined on this machine, it replies with OUTPUT=1. If the function is not defined, then the machine replies with OUTPUT=0, or with an error (invalid instruction code)

If the INPUT is set to 126 for these instructions, then, if possible, the machine will return the current setting of this function, even for the case that the function is not defined. For example, for a video switcher which always switches during the VIS of input #1, (and its VIS setting cannot be programmed otherwise), the reply to the IITX code

0A FE 80 81 (ie request VIS setting, with INPUT set as 126_{dec})

would be HEX codes

4A FE 81 81 (ie VIS setting = 1, which is defined as VIS from input #1)

NOTE 7 – Setting OUTPUT to 0 will return the VIS source setting as defined in instruction #7. Setting to 1 will return the input \bar{n} or output \bar{n} of the sync source (for the case where the VIS source is set as 6 or as 7 in instruction #7). Setting to 2 returns the vertical sync frequency (0 for no input sync, 50 for PAL, 60 for NTSC, 127 for error)

NOTE 8 - The reply is as in TYPE 3 above, except that here the OUTPUT is assigned with the value 0 if the setup is not defined / no valid input is detected; or 1 if it is defined / valid input is detected

NOTE 9 - An error code is returned to the PC if an invalid instruction code was sent to the switcher, or if a parameter associated with the instruction is out of range (e.g. trying to save to a setup greater than the highest one, or trying to switch an input or output greater than the highest one defined). This code is also returned to the PC if an RS-232 instruction is sent while the machine is being programmed via the front panel. Reception of this code by the switcher is not valid

NOTE 10 – This code is reserved for internal use

NOTE 11 For machines where the video and / or audio gain is programmable

NOTE 12 - Under normal conditions, the machine's present status is saved each time a change is made. The "power-down" save (auto-save) may be disabled using this code. Note that whenever the machine is turned on, the auto-save function is set

NOTE 13 - This is a request to identify the switcher/s in the system. If the OUTPUT is set as 0, and the INPUT is set as 1, 2, 5 or 7, the machine will send its name. The reply is the decimal value of the INPUT and OUTPUT. For example, for a 2216, the reply to the request to send the audio machine name would be (HEX codes):

7D 96 90 81 (i.e. 128_{dec}+22_{dec} for 2nd byte, and 128_{dec}+16_{dec} for 3rd byte)

If the request for identification is sent with the INPUT set as 3 or 4, the appropriate machine will send its software version number. Again, the reply would be the decimal value of the INPUT and OUTPUT - the INPUT representing the number in front of the decimal point, and the OUTPUT representing the number after it. For example, for version 3.5, the reply to the request to send the version number would be (HEX codes):

7D 83 85 81 (i.e. 128_{dec}+3_{dec} for 2nd byte, 128_{dec}+5_{dec} for 3rd byte)

If the OUTPUT is set as 1, then the ASCII coding of the lettering following the machine's name is sent. For example, for the VS-7588YC, the reply to the request to send the first suffix would be (HEX codes):

7D D9 C3 81 (i.e. 128_{dec}+ASCII for "Y"; 128_{dec}+ASCII for "C")

NOTE 14 - The number of inputs and outputs refers to the specific machine which is being addressed, *not* to the system. For example, if six 16X16 matrices are configured to make a 48X32 system (48 inputs, 32 outputs), the reply to the IITX code

3E 82 81 82 (ie request the number of outputs)

would be IITX codes

7E 82 90 82

ie 16 outputs

NOTE 15 When the OVR bit (4th byte) is set, then the "video" commands have universal meaning. For example, instruction 1 (SWITCH VIDEO) will cause all units (including audio, data, etc) to switch. Similarly, if a machine is in "FOLLOW" mode, it will perform any "video" instruction

NOTE 16 - The reply to the "REQUEST WHETHER PANEL IS LOCKED" is as in NOTE 4 above, except that here the OUTPUT is assigned with the value 0 if the panel is unlocked, or 1 if it is locked

NOTE 17 – For clean switching of RGBHV video, the "seamless switching" option may be used. The blanking period for the transition of the RGB sources may be set in this case, in steps of 25 milliseconds

For example, to set for 350ms blanking time (14 steps), send HEX codes

07 8E A0 81

NOTE 18 – Delayed execution allows switching after a delay dictated by RS-232. To do this, the user sends instruction 7 with the “Set for delayed switch” option (64_{hex}) before sending the switch command (instruction 1) or pressing via front panel. The switch is not executed (unless timed-out) until the “Execute delayed switch” code is sent, or the “Set for delayed switch” code is sent again. (The mode is automatically cancelled after implementation of the switch if the “execute” command is used.)

For example, to connect input 4 to output 3 after a delay, send HEX codes

07	80	C0	81	(set for delayed switch)
01	84	83	81	(switch code)

then, after the required delay, send HEX codes

07	80	C1	81	(execute delayed switch)
----	----	----	----	--------------------------

to implement the switch

NOTE 19 – After this instruction is sent, the unit will respond to the ASCII command set defined by the OUTPUT byte. The ASCII command to operate with the HEX command set must be sent in order to return to working with HEX codes.

NOTE 20 – When data (ie. the INPUT and/or OUTPUT bytes) of more than 7 bits is required, this instruction is sent before sending the instruction needing the additional bits. The data in this instruction then becomes the Most Significant Bits of that next instruction. For example, to set the audio gain (instruction 22) of output 3 to 681_{dec} (2A9_{hex}), you would first send HEX codes

	3F	80	85	81
--	----	----	----	----

and then send HEX codes

16	83	A9	81
----	----	----	----

To set the audio gain of output 6 to 10013_{dec} (271D_{hex}), first send HEX codes

3F	80	CE	81
----	----	----	----

followed by HEX codes

16	86	9D	81
----	----	----	----

NOTE 21 – To store data in the non-volatile memory of the unit, eg. the EEPROM for saving SETUPS. The EEPROM address is sent using the INPUT byte, and the data to be stored is sent using the OUTPUT byte. To use this instruction, it is necessary to understand the memory map, and memory structure of the particular machine.

NOTE 22 – Instruction 59 and instruction 60 load data for sending to the crosspoint switcher (or for storing in a SETUP), ie. the data is “lined-up” to be executed later. Instruction 58 executes the loaded data.

NOTE 23 – If the INPUT byte is set as 127_{dec}, then the data stored in a SETUP is loaded. The SETUP # is in the OUTPUT byte.

NOTE 24 – Further information needed in instructions 21, 22, 25 and 26, is sent using instruction 42, which is sent prior to the instruction. For example, to request the audio gain value of right input # 9, send hex codes

2A	84	80	81
----	----	----	----

and then send HEX codes

19	89	81	81
----	----	----	----

NOTE 25 – For units which detect the validity of the video inputs, Instruction 16 will be sent whenever the unit detects a change in the state of an input (in real-time).

For example, if input 3 is detected as invalid, the unit will send the HEX codes

10	83	84	81
----	----	----	----

If input 7 is detected as valid, then the unit will send HEX codes

10	87	85	81
----	----	----	----

LIMITED WARRANTY

Kramer Electronics (hereafter *Kramer*) warrants this product free from defects in material and workmanship under the following terms

HOW LONG IS THE WARRANTY

Labor and parts are warranted for seven years from the date of the first customer purchase

WHO IS PROTECTED?

Only the first purchase customer may enforce this warranty

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as below, this warranty covers all defects in material or workmanship in this product. The following are not covered by the warranty:

- 1 Any product which is not distributed by Kramer, or which is not purchased from an authorized Kramer dealer. If you are uncertain as to whether a dealer is authorized, please contact Kramer at one of the agents listed in the web site www.kramerelectronics.com
- 2 Any product, on which the serial number has been defaced, modified or removed
- 3 Damage, deterioration or malfunction resulting from:
 - i) Accident, misuse, abuse, neglect, fire, water, lightning or other acts of nature
 - ii) Product modification, or failure to follow instructions supplied with the product
 - iii) Repair or attempted repair by anyone not authorized by Kramer
 - iv) Any shipment of the product (claims must be presented to the carrier)
 - v) Removal or installation of the product
 - vi) Any other cause, which does not relate to a product defect
 - vii) Cartons, equipment enclosures, cables or accessories used in conjunction with the product

WHAT WE WILL PAY FOR AND WHAT WE WILL NOT PAY FOR

We will pay labor and material expenses for covered items. We will not pay for the following:

- 1 Removal or installation charges
- 2 Costs of initial technical adjustments (set-up), including adjustment of user controls or programming. These costs are the responsibility of the Kramer dealer from whom the product was purchased
- 3 Shipping charges

HOW YOU CAN GET WARRANTY SERVICE

- 1 To obtain service on your product, you must take or ship it prepaid to any authorized Kramer service center
- 2 Whenever warranty service is required, the original dated invoice (or a copy) must be presented as proof of warranty coverage, and should be included in any shipment of the product. Please also include in any mailing a contact name, company, address, and a description of the problem(s)
- 3 For the name of the nearest Kramer authorized service center, consult your authorized dealer

LIMITATION OF IMPLIED WARRANTIES

All implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to the length of this warranty

EXCLUSION OF DAMAGES

The liability of Kramer for any effective products is limited to the repair or replacement of the product at our option. Kramer shall not be liable for:

- 1 Damage to other property caused by defects in this product, damages based upon inconvenience, loss of use of the product, loss of time, commercial loss; or;
- 2 Any other damages, whether incidental, consequential or otherwise. Some countries may not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations and exclusions may not apply to you

This warranty gives you specific legal rights, and you may also have other rights, which vary from place to place

NOTE: All products returned to Kramer for service must have prior approval. This may be obtained from your dealer

This equipment has been tested to determine compliance with the requirements of:

- EN-50081: "Electromagnetic compatibility (EMC),
generic emission standard
Part 1: Residential, commercial and light industry"
- EN-50082: "Electromagnetic compatibility (EMC) generic immunity standard
Part 1: Residential, commercial and light industry environment"
- CFR-47: FCC Rules and Regulations:
Part 15: "Radio frequency devices
Subpart B: Unintentional radiators"

CAUTION!

- ☒ Servicing the machines can only be done by an authorized Kramer technician. Any user who makes changes or modifications to the unit without the expressed approval of the manufacturer will void user authority to operate the equipment
- ☒ Use the supplied DC power supply to feed power to the machine
- ☒ Please use recommended interconnection cables to connect the machine to other components



For the latest information on our products and a list of Kramer distributors, visit our Web site: www.kramerelectronics.com, where updates to this user manual may be found. We welcome your questions, comments and feedback.



Caution

Safety Warning:

Disconnect the unit from the power supply before opening/servicing.



Kramer Electronics, Ltd.

Web site: www.kramerelectronics.com

E-mail: info@kramercel.com

P/N: 2900-000054 REV 2