

www. xviveaudio. com

V4 FUZZ SCREAMER

Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Power supply

Please connect the designated AC adapter to an AC outlet of the correct

Please be sure to use only an AC adapter which supplies 9V(+/-10%)DC.center minus. The maximum working voltage not exceed 12V.otherwise may be dangerous equipment damage.fire or other problems. Unplug the AC power adapter when not using or during electrical storms.

Connections

Always turn off the power of this and all other equipment before connecting or disconnecting, this will help prevent malfunction and / or damage to other

Also make sure to disconnect all connection cables and the power cord before moving this unit.

Do not apply excessive force to the switches or controls. Do not let paper metallic or other objects into this unit. Take care not to drop the unit, and do not subject it to shock or excessive pressure.

Clean only with a soft,dry cloth. If necessary ,slightly moisten the cloth. Do not use abrasive cleanser, cleaning alcohol, paint thinners, wax, solvents. Cleaning fluids, or chemical-impregnated wiping cloths.

Interference with other electrical devices

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions.

To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions;

.Direct sunlight .Heat sources

.Extreme temperature or humidity .Magnetic fields .Excessive dusty or dirty location .High humidity or moisture

.Strong vibration or shocks

Main features

.A unique BITE tone control with a soft, bassy sound on one end and boosted, biting highs on the other end that lets your guitar cut through and stand out from the rest of the band.

.Total(True) bypass

.Earphone Jack

Panel instruction

1.TRUE BYPASS Footswitch:

Push down the footswitch to switch between effects And bypass status.

2.On/OFF LED:

Instructs effects or bypass status of V4 ,when the LED is lit up, the effects is on.

3. DC IN POWERJACK:

For power supply ,use a 9-volt DC REGULATED AC adapter(plug Polarity is positive on the barrel and negative in the

4.INPUT Jack:

1/4"mono audio jack, for Connecting guitar. 5.OUTPUT Jack:

1/4"mono audio jack, outputs the signal.

6. Volume Knob: Sets the overall output level.

7.SUSTAIN

Adjusts the amount of sustain and distortion

Emphasizes a range of tones, a soft bassy sound on one end and boosted biting highs on the other end..

9. Earphone Jack:

Under no AMPS, connecting the earphone when play.

Specifications

Input: 1/4" monaural jack (impedance: 10M ohms) Output: 1/4"monaural jack (impedance: 1k ohms)

Power Requirements : AC adapter 9v DC (center minus plug)

Current Draw:10 mA

Dimensions: 46 (W) *94 (D) *50 (H) mm

Accessories: Owner's manual



www. xviveaudio. com

Disclaimer: Any specification's update won't be amended in this manual

尺寸: 100*150MM

材质: 80g速写纸 正反面印